



**HIGH PERFORMANCE  
STAINLESS STEEL EXHAUSTS**

## SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULE

COD. **58.0493.00**

REV. **00** DEL. **20/07/2012** TEC-LOG **G.D.**

Descrizione **FORD S-MAX**

**Fig. 1**

**Fig. 2**

 Tagliare la nicchia sul lato destro simmetricamente a quella originale!


 Incise the niche on the right side symmetrically to the original ones!

 Entailler la niche à droite en symétrie à la niche originale!




**Fig. 3**

 Installare lo scarico completo come in figura 3!

 Install the silencers as shown in picture 3!

 Installer l'échappement complète comme dans l'image 3!

 Instalar el escape como en el imagen 3!

 Installieren Sie die gesamte Anlage wie in Abbildung 3!