



PERFORMANCE
LESS STEEL EXHAUSTS

ASSEMBLY SCHEDULE






**HIGH PERFORMANCE
STAINLESS STEEL EXHAUSTS**

Fig. 4

 Infine montare lo scarico previsto per il sottoparaurti del modello BMW 335i.

 Finally install the rear silencer specific for the rear apron of the BMW model BMW 335i.

 Enfin installer l'échappement prévu pour le pare-choc des modèles BMW 335i.

Fig. 5



Fig. 6

Fig. 7