



**HIGH PERFORMANCE
STAINLESS STEEL EXHAUSTS**

SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULE

COD. **58.0617.00**

REV. **00** DEL. **19/12/2013** TEC-LOG **G.D.**

Descrizione Fiat 500S 1.2 - 1.3MJT - 1.4 16V


Fig. 1

Fig. 2

Fig. 3

 Nel montare lo scarico prendere le misure per il taglio del tubo centrale;

 Take measures to cut the centre pipe, while installing the rear silencer;

 Prendre les mesures pour couper le tube central, lors de l'installation du silencieux arrière;





**HIGH PERFORMANCE
STAINLESS STEEL EXHAUSTS**

Fig. 4

Fig. 5

-  Installare lo scarico completo come in figura 5!
-  Install the silencers as shown in picture 5!
-  Installer l'échappement complète comme dans l'image 5!
- 